



Put all of the tablets on a table and push the «**POWER**» button on all of the tablets.



Unlock the tablet by **sliding your finger** across the screen.



Take out the stylus in the tablet to activate the stylus mode.

