




To get access to your settings, slide your finger or your stylus on your screen from top to bottom. You can directly change the brightness of your screen by moving the **slider** to the preferred brightness.



You can also click on the icon «**Settings**».

